



Overview

Includes connection and sealing components for fracturing-pump fluid ends. Check compatibility against the pump model and connection dimensions.

Selection

Specify the application, fluid, working pressure, flow rate, drive type and installation conditions. For spare parts, provide the equipment model and connection dimensions.