



Overview

Rotary-table accessories including bit-breaker adapter plates, selected for the bushing model and connections.

Construction and Configuration

Adapter plate 1816 fits 23–49½ in master bushings; 1815 fits 17½–21 in master bushings. The square opening is 13-9/16 in. Lifting tool 1021 is for bowls; lifting tool 6699 is for master bushings.

Selection

Select by equipment model, pipe diameter, rated load or torque, and connection dimensions. Check each size within the same series separately.

Technical Specifications

Applicable Tricone Bit Sizes	3-3/4、 4-1/8、 4-3/4、 5-7/8、 6、 6-1/8、 6-1/2、 7、 8-1/4、 8-1/2、 8-3/4、 9、 9-1/2、 9-5/8、 9-7/8、 12-1/4、 13-3/8、 13-3/4、 14-3/4、 15-1/2、 16、 17、 17-1/2、 18、 20、 20-1/2、 24、 26
------------------------------	---