




Overview

Includes fluid-end blocks and assembled fluid-end modules. Match each configuration to the pump model, mounting-hole positions and flow-passage connections.

Selection

Specify the application, fluid, working pressure, flow rate, drive type and installation conditions. For spare parts, provide the equipment model and connection dimensions.